

- This product is warranted for 12 months from the date of purchase.

 Subject to the conditions of this warranty, the Customer Care Centre will perform necessary service on the product without charge for parts, or labour if, in the opinion of the manufacturer/manufacturer's agent, the product is found to be faulty within the warranty period.
- This warranty only applies if the product has been installed and used in accordance with the manufacturer's recommendations (as noted in the operating instructions) under normal use and reasonable care. The warranty covers normal domestic use only and does not cover damage, malfunction or failure resulting from use of incorrect voltage, accident, misuse, neglect, build-up of dirt or dust, abuse, mis-adjustment of customer controls, mains supply problems, thunderstorm activity, infestation by insects or vermin, tampering or repair by unauthorised persons (including unauthorised alterations), exposure to abnormally corrosive conditions or any foreign object or matter having entered the product.
- If warranty service is required you should:
 - Telephone the Customer Care Centre on 1300 662 946
 - Provide a copy of your purchase receipt that shows retailer's identity and date of purchase.
 - Send or bring the product to your Customer Care Centre.
 Please note that freight to and/or from your Customer Care Centre must be arranged by you.
- The warranties hereby conferred do not extend to any costs associated with the delivery, handling, freighting or transportation of the product or any part thereof or replacement of and do not extend to any damage or loss occurring during, or associated with transit.

THIS WARRANTY CARD AND THE PURCHASE DOCKET
(OR SIMILAR PROOF OF PURCHASE)
SHOULD BE RETAINED BY THE CUSTOMER AT ALL TIMES

(03) 9321 8300

Customer Care Centre 562 Spencer Street, West Melbourne VICTORIA 3003



This advice does not limit, override or later your guaranteed rights under the Australian Consumer Law, including remedies for any failure of the Consumer Guarantees, which may include repair or replacement or it a Major Failure (as defined under the Australian Consumer Law) a replacement or refund. These guaranteed rights cannot be varied by Pro.2 or retailers of its products and have no set time limit.



1×2 HDMI SPLITTER 4K@30HZ 4:4:4

Model: PME2SP

Operating Instructions



Notice

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute the warranty of any kind, express or implied.

Features

- Simultaneously displays an Ultra HD source to two Ultra HD displays.
- Supports resolution up to 4K@30hz 4:4:4
- Support HDMI 1.4; video bandwidth up to 10.2Gbps
- Supports PCM2.0, DTS, Dolby, LPCM Max CH7.1
- Supports 3D, copy EDID

Package Contents


- 1x HDMI Splitter
- 1x 5V/1A DC Adapter
- 1x User Manual

SPECIFICATIONS


Operating Temperature Range	-5 to +35°C(+23 to +95°F)
Operating Humidity Range	5 to 90%RH (No Condensation)
Bandwidth frequency	10.2Gbps
Input ports	1xHDMI input(female)
Output ports	2xHDMI outputs(female)
Resolution outputs	up to 4K@30hz 4:4:4
Audio format	PCM2.0, DTS, Dolby, LPCM Max CH7.1
Dimensions(LxWxH)	60.8x69.5x22mm
Power consumption	1.5W(MAX)
Net Weight	120g

Note1: Specifications are subject to change without notice. Mass and dimensions are approximate.

PANEL DESCRIPTIONS



- ① HDMI output 1
- ③ HDMI output 2 indicator
- ⑤ Power indicator
- ⑦ HDMI input



- ② HDMI output 1 indicator
- 4 HDMI output 2
- 6 Power input
- 8 HDMI input indicator

EDID copy function:

The default EDID mode is to copy the EDID of sink display;

- 1. Copy 4K EDID if both displays support 4k,
- 2. Copy 1080p EDID if one display supports up to 1080p only
- 3. Copy 1080p EDID if can not read EDID of display

Connecting and operating

- 1) Connect the HDMI input source to input port of HDMI splitter.
- 2) Connect the HDMI splitter output ports to the displays.
- 3) Power up splitter, source and displays.

Connection Diagram

